
























LINSY 林氏家居		五金表/Hardware list								
安装示意图/Assembly Instruction		 (A)* 88 二合一螺杆 2-in-1-screw	 (B)* 88 大三合一锁饼 Three-in-one large lock	 (C)* 17 木榫Ø8x30mm wood tenon	 (D)* 55 自攻螺丝M3.5x12mm Self-tapping screw	编号NO.	名称Name	规格 (mm) Specification	数量QTY	材质Material
产品名称 Model NO.	T03D-A1					①	右侧板Side board(R)	2000*574*15	1	三胺板 Melamine
产品规格 Specification	1592*612*2003 mm	 (E)* 15 自攻螺丝M3.5x16mm Self-tapping screw	 (F)* 15 背板扣 Back Plate Buckle-White	 (G)* 6 香槟金一字型拉手-01 Champagne gold handle	 (H)* 6 拉手螺丝-M4x22mm pulling screw	②	左侧板Side board(L)	2000*574*15	1	三胺板 Melamine
安装工具 Tool	安装人数 Installer					③	顶板Top board	1562*574*15	1	三胺板 Melamine
		 (I)* 3 透气孔盖-白色 Vent cover - white	 (J)* 6 挂衣托-F874-B Clothes hanger	 (K)* 1 挂衣杆1 L-758 Clothes hanging rod 3	 (L)* 2 挂衣杆2 L-375 Clothes hanging rod 2	④	底板Bottom board	1562*554*15	1	三胺板 Melamine
						⑤	大层板Big shelf	765*532*15	2	三胺板 Melamine
		 (M)* 1 感应灯 Induction lamp	 (N)* 14 缓冲门铰中弯-040 Hinge-middle bending	 (O)* 20 层板托 shelf support	 (P)* 16 脚垫-灰色 Footrest - Grey	⑥	活动层板Movable shelf	382*532*15	2	三胺板 Melamine
						⑦	固定层板Fixed shelf	382*532*15	1	三胺板 Melamine
		 (Q)* 4 过山丝-M7x38mm Self-tapping screw galvanized	 (R)* 1 内六角扳手4mm spanner-(4mm) hex	 (S)* 2 三节滚珠导轨-14" three-section ball rail	 (T)* 4 L型角码14x21x1.5 L-shaped corner code	⑧	中侧板Middle side board	1912*534*15	2	三胺板 Melamine
						⑨	边背拉条Side back brace	1912*140*15	2	三胺板 Melamine
						⑩	背拉条Back brace	1912*217*15	2	三胺板 Melamine
						⑪	大背板Big backboard	1922*575*5	1	三胺板 Melamine
						⑫	小背板Small backboard	1922*152*5	2	三胺板 Melamine
						⑬	长脚条Long foot slat	1562*58*15	2	三胺板 Melamine
						⑭	中脚条Middle foot strip	522*58*15	2	三胺板 Melamine
						⑮	抽屉侧板Drawer's sideboard	395*142*15	4	三胺板 Melamine
						⑯	抽屉后板Drawer's Back board	740*142*15	2	三胺板 Melamine
						⑰	抽屉底板Drawer's Bottom board	720*405*5	2	三胺板 Melamine
						⑱	抽屉底托条Drawer's bottom bracket	395*58*15	2	三胺板 Melamine
						⑲	抽屉面板Drawer's top panel	794*242*23	2	吸塑板Blister board
						⑳	左门板Door board(L)	1950*396*23	1	吸塑板Blister board
						㉑	右门板Door board(R)	1950*396*23	1	吸塑板Blister board
						㉒	左中门板组立Left middle door panel assembly	1460*396*23	1	吸塑板+玻璃 Blister board+glass
						㉓	右中门板组立Right middle door panel assembly	1460*396*23	1	吸塑板+玻璃 Blister board+glass
						㉔	四门衣柜 配件Four door wardrobe accessories	500*52*88	1	五金 Hardware

T03D-A1


安装方法/
Installation method




大二合一
two-in-one



(A)*24




(B)*24




X2


1




(D)*12




(S)*2



(G)*2




(H)*2




(S) 副轨
Sub rail

X2


2




(A)*4




(B)*4




(P)*12




3



(A)*12




(B)*12




4

T03D-A1


安装方法/
Installation method




大二合一
two-in-one



层板托5mm
shelf support




(Q)*4
(R)*1



5


(A)*4
(B)*4
(C)*4



6

7

(A)*12
(B)*12
(C)*4




8










T03D-A1

安装方法/ Installation method

阀门开关(下压为开)
Valve switch
(press down to open)







注: 先将A与B拆下来
Note: remove a and B first



注意! 五金M: 把3M胶铁片贴在顶板的适宜位置上, 把人体感应LED灯开关调整好后放入即可使用。

Attention! Hardware M: Put the 3M rubber iron sheet on the appropriate position of the top plate, adjust the human induction LED light switch and then put it into use.



10

12

T03D-A1

安装方法/ Installation method



大弯big bend




中弯middle bending




直弯straight bending



调节上下
Adjust up and down





调节左右
Adjust left and right



调节前后
Before and after adjustment

门铰
Hinge



背板扣
Back Plate Buckle-White


(D)*20



(S)*2




D*4
D*4




端头有此图案朝前
The pattern on the end
faces forward

(S) 主轨
Main rail


13




(H)*4



(G)*4




(N)*14




14


15



(E)*14



(F)*14



16

